Contact (866) 758-3900 for assistance.
Do not return to place of purchase.

Assembly Instructions

Model No. S-1025, S-1615

Hardware/Parts

Part	Description	Qty
1	Screen	1
2	Back Foot	2
3	Front Foot	2
A	Screw	6
B	Nut	4

Tools Required for Assembly (Not Included)

Phillips Head Screw Driver and Adjustable Wrench.

Steps

Step 1

Attach back feet to screen using 2 screws (A).

Step 2

Attach front feet to screen using 4 screws (A) and 4 nuts (B).

CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.







Manufactured in China for: Blue Rhino Global Sourcing, Inc.
Winston-Salem, NC 27105 USA • 1.866.758.3900, www.uniflame.com
© Blue Rhino Global Sourcing, Inc. All Rights Reserved.
UniFlame® is a registered trademark of Blue Rhino Global Sourcing, Inc. All Rights Reserved.